



GERMAN SPRUCE

Guitar-top Guidance

As wood is a living material that reacts to changes in temperature and humidity, it is essential to store the wood correctly,
RIGHT AFTER UNPACKING!

Your wood is 100% air-seasoned and was never been inside an enclosed room. With the greatest probability the wood was packed in a different climatic condition, as you have by unpacking the wood!

Based on the difference of climatic conditions between my store, the conditions of sending and your workshop, the wood moisture can vary extremely.

If you are not sure, I suggest you to unpack your tops in a free environment (e. g., garage, shed) rather than in a controlled environment (e.g., heated living room, workshop). Store the wood also about one week in a free environment (described as follows) before you store the tops in your workshop.

To avoid the warping or even cracking of the boards, please store your wood that the air can circulate to each side of the top! You can hang each Guitar top-set on a trouser hanger (2 clamps, 2 boards)! Also you can stack the boards (making a pile with 2 sticks in between each board).

The Guitar-tops are ready to proceed after an acclimation time of about 4 weeks in your workshop by an air-humidity of 50 – 55 percent and a temperature from about 20 degrees Celsius.

I wish you much pleasure and success, with my Guitar tops. Finally, to strive for greatest SOUND is our Mission.